


BEACHCOMBER HOT TUBS



QSS Air Connect Keypad User Instructions

Bluetooth Connection:

[Note: Operating Range is up to 30 ft / 9.14 m and may vary, depending on the installation]

- 1) Turn the system on by pressing the Power On/Off key.
- 2) Press the Mode key to select the Bluetooth function. The Mode key toggles between the Bluetooth and Direct Line Aux Input functions.
- 3) When Bluetooth is active, the Bluetooth Light Indicator should be blinking blue.
- 4) Turn on the Bluetooth function of your mobile or music device.
- 5) On your mobile or music device, click search for Bluetooth device. Make sure you are in close proximity to the system.
- 6) On your mobile or music device, select "PPGME60" from the list of available devices.
- 7) Enter "6000" or "60BT" as the password (if required).
- 8) Click "Connect".
- 9) Once your mobile or music device is connected, you can now start playing your music from your device.


Direct Line Aux. Input:

[Note: With the exception of volume control, all controls and functions must be controlled from your music device in this mode]

- 1) Turn the system on by pressing the Power On/Off key.
- 2) Press the Mode key to select the Direct Line Aux. Input function. The Mode key toggles between the Bluetooth and Direct Line Aux. Input functions.
- 3) When Direct Line Aux. Input is active, the Direct Line Input Light Indicator should be blinking red.
- 4) Connect the Direct Line Aux. Input into any portable music devices.

Note: Please ensure all mobile or portable music devices are stored inside the Bluetooth compartment located on the front side of your hot tub.

BEACHCOMBER HOT TUBS



QSS Air Connect Keypad User Instructions

Bluetooth Connection:

[Note: Operating Range is up to 30 ft / 9.14 m and may vary, depending on the installation]

- 1) Turn the system on by pressing the Power On/Off key.
- 2) Press the Mode key to select the Bluetooth function. The Mode key toggles between the Bluetooth and Direct Line Aux Input functions.
- 3) When Bluetooth is active, the Bluetooth Light Indicator should be blinking blue.
- 4) Turn on the Bluetooth function of your mobile or music device.
- 5) On your mobile or music device, click search for Bluetooth device. Make sure you are in close proximity to the system.
- 6) On your mobile or music device, select "PPGME60" from the list of available devices.
- 7) Enter "6000" or "60BT" as the password (if required).
- 8) Click "Connect".
- 9) Once your mobile or music device is connected, you can now start playing your music from your device.

Direct Line Aux. Input:

[Note: With the exception of volume control, all controls and functions must be controlled from your music device in this mode]

- 1) Turn the system on by pressing the Power On/Off key.
- 2) Press the Mode key to select the Direct Line Aux. Input function. The Mode key toggles between the Bluetooth and Direct Line Aux. Input functions.
- 3) When Direct Line Aux. Input is active, the Direct Line Input Light Indicator should be blinking red.
- 4) Connect the Direct Line Aux. Input into any portable music devices.

Note: Please ensure all mobile or portable music devices are stored inside the Bluetooth compartment located on the front side of your hot tub.